

## MOUNTING REDFIELD SELF-ALIGNING BIG-BORE BASES

These bases are specially designed to correct for rifle barrels that are drilled and tapped slightly out-of-line.

The bases are provided with a lug recess to accommodate the Big-Bore Thumb Screws furnished with the Redfield "3200" Target Scope. Mounting should be at the approximate points shown in the sketch below with the lug recess to the right as shown.

When the bases are firmly mounted, loosen the ring screws until the scope slides in the rings; slide the rings along the scope tube to the point where they will fit on the bases and allow the thumb screw to fit the lug recess; tighten the thumb screws and slide the scope in the rings until the scope is properly positioned to afford the optimum eye-relief; tighten the ring screws firmly and scope is ready.

